
Maniya SERVICE MANUAL

FOR


MAMIYA PRESS SUPER 23 BLACK
(KSN)





EXPLODED VIEWS




-1-











DETAIL for cSN 1400





PARTS LIST

been ed sio error mistres that introduced to be established

PARTS LIST

METHOD OF REQUESTING SPARE PARTS FOR REPAIR USE

When ordering spare parts for repair purposes, mark the request in the following manner after referring to our parts lists.

NOTE: When ordering spare parts, always type the complete code and numbers in the Parts No. column of the appropriate parts lists.

Letters in the 'Remarks' column represent the sequence of design modification procedure, indicating that certain parts can be used in common after design modifications, while others cannot.

MAMIYA PRESS SUPER 23 BLACK (KSN)

Parts No.	ā	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
KSN 1111		Camera body	1	X	5	
CSN 1112		Sealing sponge	2	0	166.5	
CSN 1113		Sealing sponge	3	0	5	
CSN 1114		Light baffle	4	0	5	
CSN 1115		Light baffle	1	0	du# 5	
KSN 1116		Leatherette	1	0	2	
KSN 1123K2		Grip socket assy.	1	0	SuV 5	
KSN 1127		Leatherette	0.0 210.	0	2	
CSN 1131		Strap eyelet	2	0	30V 5	
KSN 1133		Flashgun mounting socket	1981	0	5	
KSN 1137		Leatherette	1	0	2	
KSN 1141		Bracket	1	0	2	
CSN 1142		Collar	2	0	2	
KSN 1143		Screw	2	0	2	
CSN 1151		Stabilizing plate	year lye	0	5	
CSN 1152		Spring washer	1	0	5 .	
CSN 1153		Tripod socket	1	0	5	
KSN 1155		Leatherette	1	0	5	
CSN 1161		Boss	2.0	0	5	
CSN 1164		Plate	1	0	2	
CSN 1165		Plate	1	0	2	
CSN 1168		Plate	2	0	5	
KSN 1171K2		Knob assy. (right)	2	0	5	
KSN 1172K2		Knob assy. (left)	2	0	1010.5	
CSN 1175		Waved washer	4	0	5	SN 182
CSN 1210K		Rear panel assy.	1	* 14	5	
CSN 1218		Leaf spring	2 - 5	0	5	SN 118
CSN 1221K2		Joint rod assy.	4	0	5	SN 105K2
CSN 1224		Screw	4	0	5	
CSN 1225		Screw	4	0	5	SN 106
CSN 1226		Sponge	. 4	0	go 2 5	SN 19997
CSN 1228		Spring washer	4	0	5	SN 1993
CSN 1231		Click	1	0	5	SN 184

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
CSN 1232	Spring	1	0	5	SN 185
KSN 1233	Screw	1	0	5	
KSN 1241	Knob	2	0	5	
CSN 1242	Screw	2	0	5	SN 111
CSN 1243	Spring	2	0	5	SN 1998
KSN 1251K	Bellows assy.	. epr l ige	0	5	
CSN 1256	Sealing sponge	e 2 1	0	5	SN 461
CSN 1311K2	Range lever assy.	1	0	4	
CSN 1313	Hub	1	0	4	
CSN 1315	Pin	1000	0	4	
CSN 1316	Nut	.usas 1 on	0	4	SN 19998
CSN 1318	Washer t=0.03 & 0.05	0 to 2	0	4	
CSN 1319	Nut	1	0	4	FC 4027
CSN 1321K2	Range lever assy.	ad partition of	0	4	
CSN 1325	Screw	1 13	0	4	
CSN 1326	Plate	1	0	4	
CSN 1327	Screw	1	0	4	
CSN 1329	Spring	1	0	4	
CSN 1331K2	Parallax lever assy.	estalq Inte	0	4	
CSN 1333	Hub	1.1	0	4	csu man.
CSN 1334	Spring	- de 1 000	0	4	
CSN 1339	Stopper	1000	0	4	
CSN 1341K2	Parallax lever assy.	1	0	4	
CSN 1347	Screw	1	0	4	
CSN 1351K2	Alarm lever assy.	1	0	4	
CSN 1353	Hub	1	0	4	
CSN 1354	Spring	eg. L(xight)	0	4	
CSN 1357K2	Signal assy.	(Marks w	0	4	
CSN 1400	Rangefinder assy.	1	w Itoria	4	
CSN 1413	Screw	2 60	0	4	
CSN 1414	Light baffle	1986	0	4	1218 T
CSN 1416	Plate	.ysal bo	0	4	
CSN 1492	Spring	1	0	4	
CSN 1493	Anchor screw	1	0	4	
KSN 1611 (H)	Top cover	1.	eixtodg	3	
KSN 1612	Screw	1:3	0	3	
CSN 1613	Plastic washer	3	0	3	

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
EFC-K4614	Shoe	1	0	3	· L. OxEWS
EFC-K4615	Stopper screw	1	0	3	
CSN 1617	Nut 9 1 63 6	4	0	3	
KSN 1618	Shoe cover	1	0	W 3	
KSN 2111	Front panel	1	*	3	
CSN 2112	Screw	8	0	3	
CSN 2113	Plate	1	0	3	
CSN 2114	Disc	4	0	2	
KSN 2115	Leatherette	1	0	2	
KSN 2116	Name plate	1	0	2	
CSN 2117	Disc	6	0	2	YP1916
CSN 2118	Sponge	2	0	3	
CSN 2119	Light baffle	1	0	3	
CSN 2121	Window glass	1	0	2	
CSN 2122	Window mask	1	0	2	
CSN 2123	Window glass	1	0	2	
CSN 2124	Milk-white film	1	0	2	
CSN 2125	Window glass	1	0	2	
KSN 2126	Window frame	. 1	0	2	
CSN 2127	Frame	1	0	.2	
KSN 2128	Spacer	1	0	2	
KSN 2131	Bayonet	1	0	3	
KSN 2132	Bayonet ring	1	0	3	
CSN 2133	Stopper	1	0	3	
CSN 2134	Shading frame	1	0	3	
CSN 2135	Screw	2	0	3	
CSN 2136	Screw	6	0	3	
CSN 2138	Screw	1	0	3	
PD2.6x4.5BNi	Screw	19	0	5	
3PB1.7x2BNi	Screw	4	0	.5	
3PB1.7x3BNi	Screw	8	0	5	
3PB1.7x2.2BNi	Screw	10	0	5	
3PB2x5BNi	Screw	2	0	4	
3PB1.7x3.5BNi	Screw	4	0	4	
PD2x3BNi	Screw	. 4	0	3	
3.8W2.5x0.1	Washer	0 to 1	0	5	
3.8W2.5x0.2	Washer	0 to 1	0	5	
6W3x0.05	Washer	0 to 3	3	3 & 5	
	_ 7 _				
	•				

Parts No.	Description	Pcs. Ref. Term Common Page of Parts No. Sale
6W3x0.1	Washer	0 to 3 0 3 & 5
6W3x0.2	Washer	0 to 3 0 3 & 5
8W4x0.05	Washer	0 to 1 0 4
8W4x0.1	Washer	0 to 1 0 4

CSW 2127.

- 4 -

Breakdown List for Special Assembly (K2)

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
KSN 1123K2	Grip socket assy.	1	0	5	
-KSN 1123	Socket	1	0		
L _{CSN} 1124	Stopper	2	0	PULSON S	SN 141-2
KSN 1171K2	Knob assy. (Right)	2	0	5	
-KSN 1171	Knob	2	X	-	
L _{CSN} 1173	Cam	2	x		SN 120-1
KSN 1172K2	Knob assy. (Left)	2	0	5	
-KSN 1172	Knob	2	x	Cidama I	
L _{CSN} 1174	Cam	2	X	NEWS P	SN 120-2
KSN 1251K	Bellows assy.	. 1	0	5	
-CSN 1251	Bellows	1	x	- A	
-KSN 1252	Frame	1	x	entrati t	CSN 1252
L _{KSN 1253}	Frame	1	x	_	CSN 1253
CSN 1311K2	Range lever assy.	1	0	4	
-CSN 1311	Lever	1	х	angana ja	
-CSN 1312	Shaft	1	X		
CSN 1347	Screw	1	x	and A	
CSN 1321K2	Range lever assy.	1	0	4	
-CSN 1321	Lever	1	x		
CSN 1322	Pin	1	x		
CSN 1323K2	Idle lever assy.	1	0	4	
-CSN 1323	Idle lever	1	X .	544-176 -	
-CSN 1324	Pin	1	X	CARLES ES	
CSN 1328	Washer	1	х	PE Unit C.	CSN 1345
CSN 1331K2	Parallax lever	1	0	4	
-CSN 1331	Lever	1	X	73,621 ×	
-CSN 1332	Shaft	1	X	included Children	
CSN 1347	Screw	1	x	electo Section 1	
CSN 1341K2	Parallax lever assy.	1	0	4	
-CSN 1341	Lever	1	x	-	
-CSN 1342	Pin	. 1	x	n.m/2	
CSN 1345	Washer	1	x		CSN 1328
CSN 1351K2	Alarm lever assy.	1	. 0	4	
-CSN 1351	Lever	1	x	e 44 -	
CSN 1352	Shaft	1	X	Top	

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
CSN 1357K2	Signal assy.	1	0	4	
-CSN 1356	Signal Signal	1	x	4	
-CSN 1357	Fixture signal	1	X	4	
Rm 1.0	Rivet	2	X	_	
CSN 1400	Rangefinder assy.	1	dellecs *	4	
-CSN 1411K2	Rangefinder assy.	1	x	6	
-CSN 1411	Rangefinder body	1	X		
-CSN 1421	Half transparent mirror	(sdraw)	x		SN 318
-CSN 1422	Metal strip	. 1	x		
-CSN 1425	Large reflex mirror	1	x		
-CSN 1426	Washer	(1)(1)	X		SASVEL MEX
-CSN 1461	Small concave lens	1	x		
-CSN 1462	Holder, small concave lens	1	x		
-CSN 1463	Cap, small concave lens	1	×		
-CSN 1465	Lens, with a hole	1	X		
CSN 1483	Bottom pivot, mirror	1	x		
-CSN 1412	Rangefinder cover	1	0	6	
-CSN 1412 -CSN 1431K2	Objective lens assy.	1	lever	6	
-CSN 1431K2 -CSN 1431	Front lens		X		
-CSN 1431 -CSN 1432	Rear lens	1	X		Post isse
	Lens holder	1	x	MEANING.	
CSN 1433	Plate	1	0	84025	
-CSN 1433		2	x	30706	
-CSN 1441	Convex lens, eyepiece	1	x	6	
-CSN 1442	Ring, convex lens	1	X	6	
-CSN 1443	Ring, eyepiece	1	X	6	
-CSN 1444	Mask, eyepiece	1	X	6	
-CSN 1445	Concave lens, eyepiece			6	
-CSN 1446	Nut	1	X	6	CAN THATER
-CSN 1447	Holder, eyepiece	1	<i>x</i>	6	
-KSN 1448	Leatherette, eyepiece	1 .		6	
-CSN 1451	Ring, eyepiece	1	X		
-CSN 1471K2	Mirror fixture assy.	l usas te	X Vol. Xal	6	
-CSN 1471	Mirror fixture	1	Х	19794	
-CSN 1472	Mirror holder	1	X .	nia	
-CSN 1474	Small reflex mirror	1	X	-deski-	
L _{CSN} 1477	Mirror holder plate	1	X	WEELS.	
Rm1.5	Rivet	2	X	Tava,V	
-CSN 1476	Leaf spring	2	X	6	
-CSN 1482	Top pivot	1	Х	6	

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
- CSN 1483	Nut	1	x	6	P. 2. 50sl. s
-CSN 1491K2	Mirror lever assy.	1	x	6	
-CSN 1491	Mirror lever	1	X	-	
L _{CSN} 1494	Stopper	1	x	-	
-CSN 1496	Screw	1	0	6	
-3PB1.7x3.5BNi	Screw	9	0	6	
-3PD1.7x3BNi	Screw	4	0	6	
-3Bs1.7x4	Adjusting screw for 1476	1	0	6	
-CSN 1511K2	Plate, bright frame assy.	1	x	6	
-CSN 1511	Plate, bright frame	1	x	6	
-CSN 1512	Shoulder rivet	1	x	6	
-CSN 1513	Boss, bright frame	2	x	6	
L _{CSN} 1519	Shoulder rivet	2	x	6	1511K2
-CSN 1516	Bright frame film	1	x	6	
-CSN 1517	Screw	1	x	6	
-CSN 1518	Shoulder screw	2	x	6	
-CSN 1519	Shoulder rivet	2	x	6	
-CSN 1521K2	Front parallax lever assy.	1	x	6	
-CSN 1521	Front parallax lever	1	x	6	
-CSN 1522	Bearing	1	x	.6	
-CSN 1523	Connector	1	X	6	
L _{CSN} 1524	Shaft, connector	1	x	6	
-CSN 1525	Spring	1	x	6	
-CSN 1526	Shaft, parallax lever	1	x	6	
-CSN 1527	Top parallax lever	1	x	6	
-CSN 1528	Shoulder screw, parallax lever	1	x	6	
-CSN 1529	Shoulder screw, connector	1	x	6	
- <u>CSN 1531K2</u>	Masking plate assy.	1	x	6	
-CSN 1531	Masking plate	1	x	6	
-CSN 1532	Guiding boss	1	x	6	
L _{CSN} 1533	Collar	2	x	6	
-CSN 1535	Supporting mask	1	x	6	
-CSN 1536	Stopper	1	x	6	
-CSN 1537	Tension spring	1	x	6	
-CSN 1541	Plate, changing bright frame	1	x	6	
-CSN 1543	Number plate, bright frame	1	x	6	
-CSN 1544	Shoulder screw	2	x	6	
-CSN 1545	Leaf spring	1	x	6	
-CSN 1547	Changing plate	1	x	6	

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
-2.5Cs1.4x2BNi	Screw	2	0	6	- CSW 1483
- 3PB1.7x2BNi	Screw	4	0	6	
- 4W2x0.3	Washer	110	vol x	6	
L8W4x0.1	Washer	0 to	1 x	6	FORN LASA

-CSN 1522

- 8 -

Plate, charging bright frame

Hand Grip

Parts No.	Description	Pcs.	Ref. Page	Term of Sale	Common Parts No.
KSN 521K2	Left hand grip assy.	1	0	7	
-CSN 521 (B)	Hand grip	1	X		
-KSN 523	Coupler	1	X	-	
-KSN 524	Coupling nut	1	X	-	
SN 546	Knock pin	1	x	-	
CSN 522 (B)	Right hand grip	1	0	7	
CSN 525K2	Trigger assy.	1	0	7	
-CSN 525	Trigger	1	x	-	
CSN 539	Disk	1	x	-	
CSN 526	Anchor screw	1	0	7	
CSN 527	Spring	1	0	7	
CSN 528 (C)	Grip plate	1	0	7	
CSN 529	Screw	1	0	7	
CSN 531	Belt plate	1	0	7	
CSN 532	Grip belt	1	0	7	
CSN 533	Screw	1	0	7	
KSN 534	Belt plate	1	0	.7	
KSN 535	Screw	1	0	7	
CSN 536K	Cable release	1	0	7	
3Ds1.7x2.2	Screw	1	0	7	
EFC-K4614	Shoe	1	0	7	
PD2x4BNi	Screw	4	0	7	
EFC-K4615	Stopper	1	0	7	
KSN 544	Cable release rack	. 1	0	7	
CSN 545	Tube	1	0	7	
EFC 4628	Shoe cover	1	0	7	
PB3x8BNi	Screw	1	0	7	
PB3x14BNi	Screw	1	0	7	
PB3x17BNi	Screw	1	0	7	